OPEN
Industry Standard, Flexible Architecture

GREEN
Less Heat, Less Power Consumption

STABLE
Robust Design, Quality Parts

Stable and
Reliable Solution

Server/Workstation
Motherboard

EP2C612D8-2T8R
EP2C612D8-8R
EP2C612D8

User Manual

English

Version 1.0
Published August 2014
Copyright©2014 ASRock Rack Inc. All rights reserved.

Copyright Notice:

No part of this documentation may be reproduced, transcribed, transmitted, or translated in any language, in any form or by any means, except duplication of documentation by the purchaser for backup purpose, without written consent of ASRock Rack Inc.

Products and corporate names appearing in this documentation may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

Disclaimer:

Specifications and information contained in this documentation are furnished for informational use only and subject to change without notice, and should not be constructed as a commitment by ASRock Rack. ASRock Rack assumes no responsibility for any errors or omissions that may appear in this documentation.

With respect to the contents of this documentation, ASRock Rack does not provide warranty of any kind, either expressed or implied, including but not limited to the implied warranties or conditions of merchantability or fitness for a particular purpose.

In no event shall ASRock Rack, its directors, officers, employees, or agents be liable for any indirect, special, incidental, or consequential damages (including damages for loss of profits, loss of business, loss of data, interruption of business and the like), even if ASRock Rack has been advised of the possibility of such damages arising from any defect or error in the documentation or product.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

CALIFORNIA, USA ONLY

The Lithium battery adopted on this motherboard contains Perchlorate, a toxic substance controlled in Perchlorate Best Management Practices (BMP) regulations passed by the California Legislature. When you discard the Lithium battery in California, USA, please follow the related regulations in advance.
"Perchlorate Material-special handling may apply, see www.dtsc.ca.gov/hazardouswaste/perchlorate"

ASRock Rack's Website: www.ASRockRack.com

Contact Information

If you need to contact ASRock Rack or want to know more about ASRock Rack, you're welcome to visit ASRock Rack's website at www.ASRockRack.com; or you may contact your dealer for further information.

ASRock Rack Incorporation

6F., No.37, Sec. 2, Jhongyang S. Rd., Beitou District,

Taipei City 112, Taiwan (R.O.C.)

Contents

Chapter 1 Introduction **1**

1.1 Package Contents 1

1.2 Specifications 2

1.3 Unique Features 5

1.4 Motherboard Layout 6

1.5 Onboard LED Indicators 13

1.6 I/O Panel 15

1.7 Block Diagram 17

Chapter 2 Installation **20**

2.1 Screw Holes 20

2.2 Pre-installation Precautions 20

2.3 Installing the CPU 21

2.4 Installing the CPU Fan and Heatsink 24

2.5 Installation of Memory Modules (DIMM) 25

2.6 Expansion Slots (PCI Express Slots) 28

2.7 Jumper Setup 29

2.8 Onboard Headers and Connectors 31

2.9 Driver Installation Guide 37

2.10 Dual LAN and Teaming Operation Guide 38

Chapter 3 UEFI Setup Utility **39**

3.1 Introduction 39

3.1.1 UEFI Menu Bar 39

3.1.2 Navigation Keys 40

3.2	Main Screen	41
3.3	Advanced Screen	42
3.3.1	ACPI Configuration	43
3.3.2	Configure Super IO Settings	44
3.3.3	Serial Port Console Redirection	45
3.3.4	CSM Configuration	48
3.3.5	USB Configuration	49
3.3.6	System Configuration	50
3.3.7	Hard Disk S.M.A.R.T Settings	51
3.3.8	3rd Storage Configuration	52
3.3.9	H/W Monitor	53
3.3.10	Instant Flash	55
3.4	IntelRCSetup	56
3.4.1	Processor Configuration	57
3.4.2	CPU Power Management Configuration	59
3.4.3	Memory Configuration	61
3.4.4	IIO Configuration	63
3.4.5	PCH Configuration	64
3.4.6	Server ME Configuration	66
3.5	Server Mgmt	67
3.6	Security	69
3.7	Boot Screen	70
3.8	Event Logs	72
3.9	Exit Screen	74

Chapter 4 Software Support **75**

4.1 Install Operating System 75

4.2 Support CD Information 75

4.2.1 Running The Support CD 75

4.2.2 Drivers Menu 75

4.2.3 Utilities Menu 75

4.2.4 Contact Information 75

Chapter 5 Troubleshooting **76**

5.1 Troubleshooting Procedures 76

5.2 Technical Support Procedures 78

5.3 Returning Merchandise for Service 78

Chapter 6: Net Framework Installation Guide **79**

6.1 Installing .Net Framework 3.5.1 (For Server 2008 R2) 79

Chapter 1 Introduction

Thank you for purchasing ASRock Rack ***EP2C612D8 / EP2C612D8-8R / EP2C612D8-2T8R*** motherboard, a reliable motherboard produced under ASRock Rack's consistently stringent quality control. It delivers excellent performance with robust design conforming to ASRock Rack's commitment to quality and endurance.

In this manual, chapter 1 and 2 contains introduction of the motherboard and step-by-step guide to the hardware installation. Chapter 3 and 4 contains the configuration guide to BIOS setup and information of the Support CD.

Because the motherboard specifications and the BIOS software might be updated, the content of this manual will be subject to change without notice. In case any modifications of this manual occur, the updated version will be available on ASRock Rack website without further notice. You may find the latest memory and CPU support lists on ASRock Rack website as well. ASRock Rack's Website: www.ASRockRack.com

If you require technical support related to this motherboard, please visit our website for specific information about the model you are using.
http://www.asrockrack.com/support

1.1 Package Contents

- ASRock Rack ***EP2C612D8 / EP2C612D8-8R / EP2C612D8-2T8R*** Motherboard (ATX Form Factor: 12" x 10", 30.5 cm x 25.4 cm)
- 4 x SATA3 Cables (50cm)
- 2 x SATA3 Cables (60cm)
- 2 x Mini SAS HD to 4 SAS/SATA Cables (12G) *(for EP2C612D8-8R and EP2C612D8-2T8R only)*
- 1 x I/O Shield
- Support CD
- User Manual

If any items are missing or appear damaged, contact your authorized dealer.

English

1.2 Specifications

EP2C612D8-8R / EP2C612D8-2T8R / EP2C612D8	
MB Physical Status	
Form Factor	ATX
Dimension	12" x 10" (30.5 cm x 25.4 cm)
Processor System	
CPU	Intel® Xeon processor E5-2600/4600 & v3 series
Socket	Dual Socket LGA 2011 R3 (Square ILM)
Chipset	Intel® C612
System Memory	
Capacity	8 DIMM slots (support NVDIMM)
Type	- Quad Channel memory technology - Supports 2133/1866/1600 LR/R/ECC and NVDIMM
Voltage	1.2V
Expansion Slot *(Slot 6 is the closest to the CPU)*	
Slot 6	x16 (CPU1)
Slot 4	x8 (CPU1)
Slot 2	x16 (CPU2)
Storage	
SATA Controller	Intel® C612 : 10 x SATA3 6 Gb/s
Additional SATA Controller	***EP2C612D8-2T8R / EP2C612D8-8R:*** LSI3008 by miniSAS HD connectors x1 (8 ports) ***EP2C612D8:*** N/A
Ethernet	
Interface	***EP2C612D8-2T8R:*** 10000/1000 /100 Mbps by Intel X540 ***EP2C612D8-8R / EP2C612D8:*** 1000 /100/10 Mbps by Intel i350

English

LAN	***EP2C612D8-2T8R:*** 2 x RJ45 10GLAN by Intel®X540 1 x RJ45 Dedicated IPMI LAN port - Supports Wake-On-LAN - Supports Energy Efficient Ethernet 802.3az - Supports Quad LAN with Teaming function - Supports PXE - LAN1 Supports NCSI ***EP2C612D8-8R / EP2C612D8:*** 2 x RJ45 GLAN by Intel® i350 1 x RJ45 Dedicated IPMI LAN port - Supports Wake-On-LAN - Supports Energy Efficient Ethernet 802.3az - Supports Dual LAN with Teaming function - Supports PXE - LAN1 Supports NCSI
Management	
BMC Controller	ASPEED AST2400
IPMI Dedicated GLAN	- 1 x Realtek RTL8211E for dedicated management GLAN
Features	- Watch Dog - NMI
Graphics	
Controller	ASPEED AST2400
VRAM	DDR3 16MB
Rear Panel I/O	
VGA Port	1 x D-Sub
USB 3.0 Port	2
USB 2.0 Port	2
Lan Port	- 2 + 1 (IPMI) Lan port (RJ45) - LAN Ports with LED (ACT/LINK LED and SPEED LED)
Serial Port	1 (COM1)
Internal Connector	
Auxiliary Panel Header	1 (includes chassis intrusion, location button & LED, front LAN LED)
TPM Header	1
IPMB Header	1
Fan Header	2x CPU Fan, 5x system Fan (4 front, 1 rear)
ATX Power	1 (24-pin) + 2 (8-pin)
USB 3.0 Header	1 (support 2 USB 3.0)
USB 2.0 Header	1 (support 2 USB 2.0)
Type A USB 3.0 Port	1

System BIOS	
BIOS Type	128Mb AMI UEFI Legal BIOS
BIOS Features	- Plug and Play (PnP) - ACPI 2.0 Compliance Wake Up Events - SMBIOS 2.8 Support - ASRock Rack Instant Flash
Hardware Monitor	
Temperature	- CPU Temperature Sensing - MB Temperature Sensing - Card Side Temperature Sensing
Fan	- CPU/Rear/Front Fan Tachometer - CPU Quiet Fan (Allow CPU Fan Speed Auto-Adjust by CPU Temperature) - CPU/Rear/Front Fan Multi-Speed Control
Voltage	Voltage Monitoring: +12V, +5V, +3.3V, CPU Vcore, DRAM, 1.05V_PCH, +BAT, 3VSB, 5VSB
Support OS	
OS	Microsoft® Windows® - Server 2008 R2 SP1 (64 bit) - Server 2012 (64 bit) - Server 2012 R2 (64 bit) Linux® - RedHat Enterprise Linux Server 5.10/6.5 (32 / 64 bit) - CentOS 5.10 / 6.5 (32 / 64 bit) - SUSE Enterprise Linux Server 11 SP3 (32 / 64 bit) - FreeBSD 9.2 (32 / 64 bit) - Fedora core 19 (64 bit) - Ubuntu 12.04.2 (64 bit) / 12.10 (64 bit) Virtual - VMWare® ESXi 5.5
Environment	
Temperature	Operation temperature: 10°C ~ 35°C / Non operation temperature: -40°C ~ 70°C

This motherboard supports Wake from on Board LAN. To use this function, please make sure that the "Wake on Magic Packet from power off state" is enabled in Device Manager > Intel® Ethernet Connection > Power Management. And the "PCI Devices Power On" is enabled in UEFI SETUP UTILITY > Advanced > ACPI Configuration. After that, onboard LAN1&2 can wake up S5 under OS.

If you install Intel® LAN utility or Marvell SATA utility, this motherboard may fail Windows® Hardware Quality Lab (WHQL) certification tests. If you install the drivers only, it will pass the WHQL tests.

1.3 Unique Features

ASRock Rack Instant Flash is a BIOS flash utility embedded in Flash ROM. This convenient BIOS update tool allows you to update system BIOS without entering operating systems first like MS-DOS or Windows®. With this utility, you can press the <F6> key during the POST or the <F2> key to enter into the BIOS setup menu to access ASRock Rack Instant Flash. Just launch this tool and save the new BIOS file to your USB flash drive, floppy disk or hard drive, then you can update your BIOS only in a few clicks without preparing an additional floppy diskette or other complicated flash utility. Please be noted that the USB flash drive or hard drive must use FAT32/16/12 file system.

1.4 Motherboard Layout

EP2C612D8-2T8R



EP2C612D8-8R



English

No.	Description
1	2 x 288-pin DDR4 DIMM Slots (DDR4_G, DDR4_H, Blue)
2	ATX 12V Power Connector (ATX12V3)
3	PSU SMBus (PSU_SMB1)
4	ATX Power Connector (ATXPWR1)
5	ATX 12V Power Connector (ATX12V2)
6	2 x 288-pin DDR4 DIMM Slots (DDR4_A, DDR4_B, Blue)
7	Front Fan Connector (FRONT_FAN3)
8	CPU1 Fan Connector (CPU1_FAN)
9	2 x 288-pin DDR4 DIMM Slots (DDR4_C, DDR4_D, Blue)
10	Front Fan Connector (FRONT_FAN4)
11	Front Fan Connector (FRONT_FAN2)
12	SATA SGPIO Connector (SATA_SGPIO1)
13	SATA SGPIO Connector (SATA_SGPIO2)
14	USB 3.0 Header (USB3_2_3)
15	Mini SAS HD Connector (LSI_SAS_0_7)
16	Chassis ID2 Jumper (Chassis_ ID0_2)
17	Chassis ID3 Jumper (Chassis_ ID0_3)
18	Chassis ID1 Jumper (Chassis_ ID0_1)
19	SCU Connector (SCU_1), White
20	Front Fan Connector (FRONT_FAN1)
21	SCU Connector (SCU_0), White
22	SCU Connector (SCU_2), White
23	SCU Connector (SCU_3), White
24	SATA3 Connector (SATA_1), White
25	SATA3 Connector (SATA_0), White
26	SATA3 Connector (SATA_3), White
27	SATA3 Connector (SATA_2), White
28	SATA3 Connector (SATA_5), White
29	SATA3 Connector (SATA_4), White
30	Vertical Type A USB 3.0 (USB3_5)
31	System Panel Header (PANEL1)
32	Speaker Header (SPEAKER1)
33	Auxiliary Panel Header (AUX_PANEL1)

No.	Description
34	ME Recovery Jumper (ME_RECOVERY1)
35	CPU PECI Mode Jumper (PECI_SEL1)
36	Descriptor Security Override Jumper (J100)
37	PMBUS Mode Jumper (PMBUS_SEL_DAT1)
38	TPM Header (TPM1)
39	PMBUS Mode Jumper (PMBUS_SEL_ALT1)
40	BMC SMBus Header (BMC_SMB_3)
41	Rear Fan Connector (REAR_FAN1)
42	BMC SMBus Header (BMC_SMB_2)
43	BMC SMBus Header (BMC_SMB_1)
44	PMBUS Mode Jumper (PMBUS_SEL_CLK1)
45	Intelligent Platform Management Bus header (IPMB_1)
46	Non Maskable Interrupt Button (NMI_BTN1)
47	2 x 288-pin DDR4 DIMM Slots (DDR4_E, DDR4_F, Blue)
48	CPU 2 Fan Connector (CPU2_FAN)

**For DIMM installation and configuration instructions, please see p.23 (Installation of Memory Modules (DIMM)) for more details.*

EP2C612D8



English

No.	Description
1	2 x 288-pin DDR4 DIMM Slots (DDR4_G, DDR4_H, Blue)
2	ATX 12V Power Connector (ATX12V3)
3	PSU SMBus (PSU_SMB1)
4	ATX Power Connector (ATXPWR1)
5	ATX 12V Power Connector (ATX12V2)
6	2 x 288-pin DDR4 DIMM Slots (DDR4_A, DDR4_B, Blue)
7	Front Fan Connector (FRONT_FAN3)
8	CPU1 Fan Connector (CPU1_FAN)
9	2 x 288-pin DDR4 DIMM Slots (DDR4_C, DDR4_D, Blue)
10	Front Fan Connector (FRONT_FAN4)
11	Front Fan Connector (FRONT_FAN2)
12	SATA SGPIO Connector (SATA_SGPIO1)
13	SATA SGPIO Connector (SATA_SGPIO2)
14	USB 3.0 Header (USB3_2_3)
15	Chassis ID2 Jumper (Chassis_ ID0_2)
16	Chassis ID3 Jumper (Chassis_ ID0_3)
17	Chassis ID1 Jumper (Chassis_ ID0_1)
18	SCU Connector (SCU_1), White
19	Front Fan Connector (FRONT_FAN1)
20	SCU Connector (SCU_0), White
21	SCU Connector (SCU_2), White
22	SCU Connector (SCU_3), White
23	SATA3 Connector (SATA_1), White
24	SATA3 Connector (SATA_0), White
25	SATA3 Connector (SATA_3), White
26	SATA3 Connector (SATA_2), White
27	SATA3 Connector (SATA_5), White
28	SATA3 Connector (SATA_4), White
29	Vertical Type A USB 3.0 (USB3_5)
30	System Panel Header (PANEL1)
31	Speaker Header (SPEAKER1)
32	Auxiliary Panel Header (AUX_PANEL1)
33	ME Recovery Jumper (ME_RECOVERY1)

No.	Description
34	CPU PECI Mode Jumper (PECI_SEL1)
35	Descriptor Security Override Jumper (J100)
36	PMBUS Mode Jumper (PMBUS_SEL_DAT1)
37	TPM Header (TPM1)
38	PMBUS Mode Jumper (PMBUS_SEL_ALT1)
39	BMC SMBus Header (BMC_SMB_3)
40	Rear Fan Connector (REAR_FAN1)
41	BMC SMBus Header (BMC_SMB_2)
42	BMC SMBus Header (BMC_SMB_1)
43	PMBUS Mode Jumper (PMBUS_SEL_CLK1)
44	Intelligent Platform Management Bus header (IPMB_1)
45	Non Maskable Interrupt Button (NMI_BTN1)
46	2 x 288-pin DDR4 DIMM Slots (DDR4_E, DDR4_F, Blue)
47	CPU 2 Fan Connector (CPU2_FAN)

**For DIMM installation and configuration instructions, please see p.23 (Installation of Memory Modules (DIMM)) for more details.*

1.5 Onboard LED Indicators



English

No.	Status	Description
1	Amber	FRNT_FAN3 failed
2	Amber	CPU1_FAN failed
3	Amber	FRNT_FAN4 failed
4	Amber	FRNT_FAN2 failed
5	Green	STB PWR ready
6	Amber	FRNT_FAN1 failed
7	Amber	Rear_FAN2 failed
8	Green	BMC heartbeat LED
9	Amber	CPU2_FAN failed

1.6 I/O Panel

EP2C612D8-8R / EP2C612D8



No.	Description	No.	Description
1	Serial Port (COM1)	5	USB 3.0 Ports (USB3_1-2)
2	VGA Port (VGA1)	6	1G LAN RJ-45 Port (LAN1)**
3	USB 2.0 Ports (USB_1-2)	7	1G LAN RJ-45 Port (LAN2)**
4	LAN RJ-45 Port (IPMI_LAN)*		

EP2C612D8-2T8R



No.	Description	No.	Description
1	Serial Port (COM1)	5	USB 3.0 Ports (USB3_1-2)
2	VGA Port (VGA1)	6	10G LAN RJ-45 Port (LAN1)**
3	USB 2.0 Ports (USB_1-2)	7	10G LAN RJ-45 Port (LAN2)**
4	LAN RJ-45 Port (IPMI_LAN)*		

** System air-flow is required for cooling the onboard Intel Ethernet Controller X540 heat sink.*

LAN Port LED Indications

*There are two LED next to the LAN port. Please refer to the table below for the LAN port LED indications.



Dedicated IPMI LAN Port LED Indications

Activity / Link LED		Speed LED	
Status	Description	Status	Description
Off	No Link	Off	10M bps connection or no link
Blinking Yellow	Data Activity	Yellow	100M bps connection
On	Link	Green	1G bps connection

**There are two LEDs on each LAN port. Please refer to the table below for the LAN port LED indications.



LAN Port (LAN1, LAN2) LED Indications

1G For EP2C612D8-8R / EP2C612D8

Speed LED		Activity / Link LED	
Status	Description	Status	Description
Off	10Mbps connection or no link	Off	No link
Yellow	100Mbps connection	Blinking Green	Data Activity
Green	1Gbps connection	On	Link

10G For EP2C612D8-2T8R

Speed LED		Activity / Link LED	
Status	Description	Status	Description
Off	100Mbps connection or no link	Off	No link
Yellow	1Gbps connection	Blinking Green	Data Activity
Green	10Gbps connection	On	Link

1.7 Block Diagram

EP2C612D8



EP2C612D8-8R



EP2C612D8-2T8R



Chapter 2 Installation

This is an ATX form factor (12" x 10", 30.5 cm x 25.4 cm) motherboard. Before you install the motherboard, study the configuration of your chassis to ensure that the motherboard fits into it.

EP2C612 Series are dual socket motherboards that support Intel® Xeon® E5-2600 v3 Series Processors. Please install a primary processor (BootStrap Processor) into "CPU1" socket and then install a non-Primary Processor (Application Processors) into "CPU2" socket. *For a single CPU, please install it into "CPU1" socket (framed by a square).

Make sure to unplug the power cord before installing or removing the motherboard. Failure to do so may cause physical injuries to you and damages to motherboard components.

2.1 Screw Holes

Place screws into the holes indicated by circles to secure the motherboard to the chassis.

Do not over-tighten the screws! Doing so may damage the motherboard.

2.2 Pre-installation Precautions

Take note of the following precautions before you install motherboard components or change any motherboard settings.

1. Unplug the power cord from the wall socket before touching any components.
2. To avoid damaging the motherboard's components due to static electricity, NEVER place your motherboard directly on the carpet or the like. Also remember to use a grounded wrist strap or touch a safety grounded object before you handle the components.
3. Hold components by the edges and do not touch the ICs.
4. Whenever you uninstall any component, place it on a grounded anti-static pad or in the bag that comes with the component.
5. When placing screws into the screw holes to secure the motherboard to the chassis, please do not over-tighten the screws! Doing so may damage the motherboard.

Before you install or remove any component, ensure that the power is switched off or the power cord is detached from the power supply. Failure to do so may cause severe damage to the motherboard, peripherals, and/or components.

English

2.3 Installing the CPU

1. *Before you insert the 2011-3-Pin CPU into the socket, please check if the PnP cap is on the socket, if the CPU surface is unclean, or if there are any bent pins in the socket. Do not force to insert the CPU into the socket if above situation is found. Otherwise, the CPU will be seriously damaged.*
2. *Unplug all power cables before installing the CPU.*

CAUTION:

Please note that C612 platform is only compatible with the LGA 2011-3 socket, which is incompatible with the LGA 2011 socket

Socket Type: Square ILM Socket

1



2



English

3



4



5



6



7



8



The cover must be placed if returning the motherboard for after service.

2.4 Installing the CPU Fan and Heatsink

Before you installed the heatsink, you need to spray thermal interface material between the CPU and the heatsink to improve heat dissipation.

9



10



11



2.5 Installation of Memory Modules (DIMM)

This motherboard provides eight 288-pin DDR4 (Double Data Rate 4) DIMM slots in two groups, and supports Dual Channel Memory Technology.

Capacity	CPU1	CPU2
256GB/ 512GB	DDR4_A, B, C, D	DDR4_E, F, G, H

1. *It is not allowed to install a DDR, DDR2 or DDR3 memory module into a DDR4 slot; otherwise, this motherboard and DIMM may be damaged.*
2. *For dual channel configuration, you always need to install identical (the same brand, speed, size and chip-type) DDR4 DIMM pairs.*
3. *It is unable to activate Dual Channel Memory Technology with only one or three memory module installed.*
4. *Some DDR4 1GB double-sided DIMMs with 16 chips may not work on this motherboard. It is not recommended to install them on this motherboard.*

1



2



3



The DIMM only fits in one correct orientation. It will cause permanent damage to the motherboard and the DIMM if you force the DIMM into the slot at incorrect orientation.

Recommended Memory Configurations

A single memory module should be installed in the BLUE socket.

If you install only one CPU (CPU1) on the motherboard, make sure to install DIMMs into DDR4_A, DDR4_B, DDR4_C, or DDR4_D slot(s).

1 CPU Configuration

	CPU1			
	A	B	C	D
1 DIMM	#			
2 DIMMS	#	#		
4 DIMMS	#	#	#	#

**The # mark indicates the slot is populated.*

2 CPU Configuration

	CPU1				CPU2			
	A	B	C	D	E	F	G	H
1 DIMM	#							
2 DIMMS	#	#						
4 DIMMS	#	#	#	#				
8 DIMMS	#	#	#	#	#	#	#	#

2.6 Expansion Slots (PCI Express Slots)

There are 3 PCI Express slots on this motherboard.

PCIE slot:

PCIE4 (PCIE 3.0 x8 slot, from CPU 1) is used for PCI Express x8 lane width graphics cards.
PCIE6 (PCIE 3.0 x16 slot, from CPU 1) is used for PCI Express x16 lane width graphics cards.
PCIE2 (PCIE 3.0 x16 slot, from CPU 2) is used for PCI Express x16 lane width graphics cards.

Slot	Generation	Mechnical	Eletrical	Source
PCIE 6	3.0	x16	x16	CPU 1
PCIE 4	3.0	x8	x8	CPU 1
PCIE 2	3.0	x16	x16	CPU 2

PCI Express Slot Configuration

	PCIE 6	PCIE2
Single Graphics Card	x16	
Two Graphics Cards	x8	x8

2.7 Jumper Setup

The illustration shows how jumpers are setup. When the jumper cap is placed on the pins, the jumper is "Short". If no jumper cap is placed on the pins, the jumper is "Open". The illustration shows a 3-pin jumper whose pin1 and pin2 are "Short" when a jumper cap is placed on these 2 pins.



ME Recovery Jumper (3-pin ME_RECOVERY1)	1_2 ME Recovery Mode	2_3 Normal Mode (Default)
Override Mode Jumper (3-pin J100)	1_2 Descriptor Security Override	2_3 No Override (Default)
CPU PECI Mode Jumper (3-pin PECI_SEL1)	1_2 CPU PECI connect to PCH	2_3 CPU PECI connect to BMC (Default)
PMBUS CLK Mode Jumper (3-pin PMBUS_SEL_CLK1)	1_2 PMBUS CLK to BMC (Default)	2_3 PMBUS CLK to PCH
PMBUS DATA Mode Jumper (3-pin PMBUS_SEL_DAT1)	1_2 PMBUS DATA to BMC (Default)	2_3 PMBUS DATA to PCH

PMBUS ALERT Mode Jumper (3-pin PMBUS_SEL_ALT1)	PMBUS ALERT# to BMC (Default)	PMBUS ALERT# to PCH
Chassis ID1 Jumper (3-pin CHASSIS_ID0_1) Chassis ID2 Jumper (3-pin CHASSIS_ID0_2) Chassis ID3 Jumper (3-pin CHASSIS_ID0_3)	 Board Level SKU (Default)	 Reserved for system level use
Chassis ID1 Jumper (3-pin CHASSIS_ID0_1) Chassis ID2 Jumper (3-pin CHASSIS_ID0_2) Chassis ID3 Jumper (3-pin CHASSIS_ID0_3)	 Reserved for system level use	 Reserved for system level use
Chassis ID1 Jumper (3-pin CHASSIS_ID0_1) Chassis ID2 Jumper (3-pin CHASSIS_ID0_2) Chassis ID3 Jumper (3-pin CHASSIS_ID0_3)	 Reserved for system level use	 Reserved for system level use

2.8 Onboard Headers and Connectors

Onboard headers and connectors are NOT jumpers. Do NOT place jumper caps over these headers and connectors. Placing jumper caps over the headers and connectors will cause permanent damage to the motherboard.

System Panel Header
(9-pin PANEL1)



Connect the power switch, reset switch and system status indicator on the chassis to this header according to the pin assignments. Particularly note the positive and negative pins before connecting the cables.

PWRBTN (Power Switch):
Connect to the power switch on the chassis front panel. You may configure the way to turn off your system using the power switch.

RESET (Reset Switch):
Connect to the reset switch on the chassis front panel. Press the reset switch to restart the computer if the computer freezes and fails to perform a normal restart.

PLED (System Power LED):
Connect to the power status indicator on the chassis front panel. The LED is on when the system is operating. The LED keeps blinking when the system is in S1/S3 sleep state. The LED is off when the system is in S4 sleep state or powered off (S5).

HDLED (Hard Drive Activity LED):
Connect to the hard drive activity LED on the chassis front panel. The LED is on when the hard drive is reading or writing data.

The front panel design may differ by chassis. A front panel module mainly consists of power switch, reset switch, power LED, hard drive activity LED, speaker and etc. When connecting your chassis front panel module to this header, make sure the wire assignments and the pin assignments are matched correctly.

Auxiliary Panel Header
(18-pin AUX PANEL1)



This header supports multiple functions on the front panel, including the front panel SMB, internet status indicator and chassis intrusion pin.

A. Front panel SMBus connecting pin (6-1 pin FPSMB)
This header allows you to connect SMBus (System Management Bus) equipment. It can be used for communication between peripheral equipment in the system, which has slower transmission rates, and power management equipment.

B. Internet status indicator (2-pin LAN1_LED, LAN2_LED)
These two 2-pin headers allow you to use the Gigabit internet indicator cable to connect to the LAN status indicator. When this indicator flickers, it means that the internet is properly connected.

C. Chassis intrusion pin (2-pin CHASSIS)
This header is provided for host computer chassis with chassis intrusion detection designs. In addition, it must also work with external detection equipment, such as a chassis intrusion detection sensor or a microswitch. When this function is activated, if any chassis component movement occurs, the sensor will immediately detect it and send a signal to this header, and the system will then record this chassis intrusion event. The default setting is set to the CASEOPEN and GND pin; this function is off.

D. Locator LED (6-pin LOCATOR)
This header is for the locator switch and LED on the front panel.

English

Serial ATA3 Connectors
(SATA_0)
(SATA_1)
(SATA_2)
(SATA_3)
(SATA_4)
(SATA_5)



These ten SATA3 connectors support SATA data cables for internal storage devices with up to 6.0 Gb/s data transfer rate.

SCU Connectors
(SCU_0)
(SCU_1)
(SCU_2)
(SCU_3)



This SCU connector supportsSATA data cables for internal storage devices with up to 6.0 Gb/s data transfer rate. For connecting SAS HDDs, please contact SAS data cable dealers.

Mini SAS HD Connector
(LSI_SAS_0_7)
**Not supported for EP2C612D8 motherboard*



This Mini SAS HD connector supports SAS/ SATA data cables for internal storage devices.
The current SAS3/SATA3 interface allows up to 12.0 Gb/s data transfer rate. For connecting SAS HDDs, please contact SAS data cable dealers.

USB 2.0 Connector (USB3_5)		
USB 3.0 Header (19-pin USB3_2_3)		Besides two default USB 3.0 ports on the I/O panel, there is one USB 3.0 header on this motherboard. This USB 3.0 header can support two USB 3.0 ports.
Chassis Speaker Header (4-pin SPEAKER1)		Please connect the chassis speaker to this header.
CPU Fan Connectors (4-pin CPU1_FAN) (4-pin CPU2_FAN)		This motherboard provides two 4-Pin CPU fan (Quiet Fan) connectors. If you plan to connect a 3-Pin CPU fan, please connect it to Pin 1-3.

English

Front and Rear Fan Connectors
(4-pin FRNT_FAN1)
(4-pin FRNT_FAN2)
(4-pin FRNT_FAN3)
(4-pin FRNT_FAN4)
(4-pin REAR_FAN1)







Please connect fan cables to the fan connectors and match the black wire to the ground pin. All fans support Fan Control.

ATX Power Connector
(24-pin ATXPWR1)



This motherboard provides a 24-pin ATX power connector. To use a 20-pin ATX power supply, please plug it along Pin 1 and Pin 13.

ATX 12V Power Connectors
(8-pin ATX12V2)
(8-pin ATX12V3)



This motherboard provides two 8-pin ATX 12V power connectors.

TPM Header
(17-pin TPM1)



This connector supports Trusted Platform Module (TPM) system, which can securely store keys, digital certificates, passwords, and data. A TPM system also helps enhance network security, protects digital identities, and ensures platform integrity.

English

Serial General Purpose Input/Output Headers (7-pin SATA_SGPIO1) (7-pin SATA_SGPIO2)		These headers support Serial Link interface for onboard SATA connections.
PSU SMBus (5-pin PSU_SMB1)		PSU SMBus monitors the status of the power supply, fan and system temperature.
Non Maskable Interrupt Button Header (2-pin NMI_BTN1)		Please connect a NMI device to this header.
Intelligent Platform Management Bus header (4-pin IPMB_1)		This 4-pin connector is used to provide a cabled base-board or front panel connection for value added features and 3rd-party add-in cards, such as Emergency Management cards, that provide management features using the IPMB.
Baseboard Management Controller SMBus Headers (5-pin BMC_SMB_1) (5-pin BMC_SMB_2) (5-pin BMC_SMB_3)		These headers are used for the SM BUS devices..

English

2.9 Driver Installation Guide

To install the drivers to your system, please insert the support CD to your optical drive first. Then, the drivers compatible to your system can be auto-detected and listed on the support CD driver page. Please follow the order from top to bottom to install those required drivers. Therefore, the drivers you install can work properly.

2.10 Dual LAN and Teaming Operation Guide

Dual LAN with Teaming enabled on this motherboard allows two single connections to act as one single connection for twice the transmission bandwidth, making data transmission more effective and improving the quality of transmission of distant images. Fault tolerance on the dual LAN network prevents network downtime by transferring the workload from a failed port to a working port.

The speed of transmission is subject to the actual network environment or status even with Teaming enabled.

Before setting up Teaming, please make sure whether your Switch (or Router) supports Teaming (IEEE 802.3ad Link Aggregation). You can specify a preferred adapter in Intel PROSet. Under normal conditions, the Primary adapter handles all non-TCP/IP traffic. The Secondary adapter will receive fallback traffic if the primary fails. If the Preferred Primary adapter fails, but is later restored to an active status, control is automatically switched back to the Preferred Primary adapter.

Step 1

From **Device Manager**, open the properties of a team.

Step 2

Click the **Settings** tab.

Step 3

Click the **Modify Team** button.

Step 4

Select the adapter you want to be the primary adapter and click the **Set Primary** button.

If you do not specify a preferred primary adapter, the software will choose an adapter of the highest capability (model and speed) to act as the default primary. If a failover occurs, another adapter becomes the primary. The adapter will, however, rejoin the team as a non-primary.

Chapter 3 UEFI Setup Utility

3.1 Introduction

This section explains how to use the UEFI SETUP UTILITY to configure your system. The UEFI chip on the motherboard stores the UEFI SETUP UTILITY. You may run the UEFI SETUP UTILITY when you start up the computer. Please press <F2> or <Del> during the Power-On-Self-Test (POST) to enter the UEFI SETUP UTILITY; otherwise, POST will continue with its test routines.

If you wish to enter the UEFI SETUP UTILITY after POST, restart the system by pressing <Ctrl> + <Alt> + <Delete>, or by pressing the reset button on the system chassis. You may also restart by turning the system off and then back on.

Because the UEFI software is constantly being updated, the following UEFI setup screens and descriptions are for reference purpose only, and they may not exactly match what you see on your screen.

3.1.1 UEFI Menu Bar

The top of the screen has a menu bar with the following selections:

Item	Description
Main	To set up the system time/date information
Advanced	To set up the advanced UEFI features
IntelRCSetup	For Intel CPU and chipset settings
Server Mgmt	To manage the server
Security	To set up the security features
Boot	To set up the default system device to locate and load the Operating System
Event Logs	For event log configuration
Exit	To exit the current screen or the UEFI SETUP UTILITY

Use <←> key or <→> key to choose among the selections on the menu bar, and then press <Enter> to get into the sub screen.

English

3.1.2 Navigation Keys

Please check the following table for the function description of each navigation key.

Navigation Key(s)	Function Description
← / →	Moves cursor left or right to select Screens
↑ / ↓	Moves cursor up or down to select items
+ / -	To change option for the selected items
<Tab>	Switch to next function
<Enter>	To bring up the selected screen
<PGUP>	Go to the previous page
<PGDN>	Go to the next page
<HOME>	Go to the top of the screen
<END>	Go to the bottom of the screen
<F1>	To display the General Help Screen
<F7>	Discard changes and exit the UEFI SETUP UTILITY
<F9>	Load optimal default values for all the settings
<F10>	Save changes and exit the UEFI SETUP UTILITY
<F12>	Print screen
<ESC>	Jump to the Exit Screen or exit the current screen

3.2 Main Screen

Once you enter the UEFI SETUP UTILITY, the Main screen will appear and display the system overview. The Main screen provides system overview information and allows you to set the system time and date.


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
Main Advanced IntelRCSetup Server Mgmt Security Boot Event Logs Exit
UEFI Version : EP2C612D8-8R L0.23
BMC Version : 7.1.0
Processor Type : Genuine Intel(R) CPU @ 2.90GHz
Processor Speed : 2900MHz
Microcode Update : 306F1/14
Cache Size : 36128KB
Total Memory : 4096MB(DDR4-1866)
System Date [Mon 06/04/2014]
System Time [23:58:22]
Set the Date. Use Tab to switch between Date elements.
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

English

3.3 Advanced Screen

In this section, you may set the configurations for the following items: ACPI Configuration, Configure Super IO Settings, Serial Port Console Redirection, CSM Configuration, USB Configuration, System Configuration, Hard Disk S.M.A.R.T Settings, 3rd Storage Configuration, H/W Monitor and Instant Flash.



Setting wrong values in this section may cause the system to malfunction.

English

3.3.1 ACPI Configuration


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
Advanced
PCIE Devices Power On [Disabled]
Ring-In Power On [Disabled]
RTC Alarm Power On [By OS]
Allow the system to be waked up by a PCI device and enable wake on LAN.
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

PCIE Devices Power On

Use this item to enable or disable PCIE devices to turn on the system from the power-soft-off mode.

Ring-In Power On

Use this item to enable or disable Ring-In signals to turn on the system from the power-soft-off mode.

RTC Alarm Power On

Use this item to enable or disable RTC (Real Time Clock) to power on the system.

3.3.2 Configure Super IO Settings



Serial Port 1 Configuration

Use this item to configure the onboard serial port 1.

Select and enter the "Serial Port 1 Configuration" and you will see the followings:

Serial Port
Use this item to enable or disable the onboard serial port.

Serial Port Address
Use this item to select an optimal setting for Super IO device.

SOL Configuration

Use this item to set parameters of SOL.

3.3.3 Serial Port Console Redirection



COM1 / SOL

Console Redirection

Use this option to enable or disable Console Redirection. If this item is set to Enabled, you can select a COM Port to be used for Console Redirection.

Console Redirection Settings

Use this option to configure Console Redirection Settings, and specify how your computer and the host computer to which you are connected exchange information.

Terminal Type

Use this item to select the preferred terminal emulation type for out-of-band management. It is recommended to select [VT-UTF8].

Option	Description
VT100	ASCII character set
VT100+	Extended VT100 that supports color and function keys
VT-UTF8	UTF8 encoding is used to map Unicode chars onto 1 or more bytes
ANSI	Extended ASCII character set

Bits Per Second
Use this item to select the serial port transmission speed. The speed used in the host computer and the client computer must be the same. Long or noisy lines may require lower transmission speed. The options include [9600], [19200], [57600] and [115200].

Data Bits
Use this item to set the data transmission size. The options include [7] and [8] (Bits).

Parity
Use this item to select the parity bit. The options include [None], [Even], [Odd], [Mark] and [Space].

Stop Bits
The item indicates the end of a serial data packet. The standard setting is [1] Stop Bit. Select [2] Stop Bits for slower devices.

Flow Control
Use this item to set the flow control to prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a "stop" signal can be sent to stop the data flow. Once the buffers are empty, a "start" signal can be sent to restart the flow. Hardware flow uses two wires to send start/stop signals. The options include [None] and [Hardware RTS/CTS].

VT-UTF8 Combo Key Support
Use this item to enable or disable the VT-UTF8 Combo Key Support for ANSI/VT100 terminals.

Recorder Mode
Use this item to enable or disable Recorder Mode to capture terminal data and send it as text messages.

Resolution 100x31
Use this item to enable or disable extended terminal resolution support.

Legacy OS Redirection Resolution
Use this item to select the number of rows and columns used in legacy OS redirection.

Putty Keypad
Use this item to select Function Key and Keypad on Putty.

Redirection After BIOS POST
If the [BootLoader] is selected, legacy console redirection is disabled before booting to legacy OS. If [Always Enabled] is selected, legacy console redirection is enabled for legacy OS. The default value is [Always Enabled].

Serial Port for Out-of-Band Management/Windows Emergency Management Services (EMS)

Console Redirection

Use this option to enable or disable Console Redirection. If this item is set to Enabled, you can select a COM Port to be used for Console Redirection.

Console Redirection Settings

Use this option to configure Console Redirection Settings, and specify how your computer and the host computer to which you are connected exchange information.

Terminal Type
Use this item to select the preferred terminal emulation type for out-of-band management. It is recommended to select [VT-UTF8].

Option	Description
VT100	ASCII character set
VT100+	Extended VT100 that supports color and function keys
VT-UTF8	UTF8 encoding is used to map Unicode chars onto 1 or more bytes
ANSI	Extended ASCII character set

Bits Per Second
Use this item to select the serial port transmission speed. The speed used in the host computer and the client computer must be the same. Long or noisy lines may require lower transmission speed. The options include [9600], [19200], [57600] and [115200].

Flow Control
Use this item to set the flow control to prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a "stop" signal can be sent to stop the data flow. Once the buffers are empty, a "start" signal can be sent to restart the flow. Hardware flow uses two wires to send start/stop signals. The options include [None], [Hardware RTS/CTS], and [Software Xon/Xoff].

Data Bits
Use this item to set the data transmission size. The standard setting is [8] (Bits).

Parity
Use this item to select the parity bit. The standard setting is [None].

Stop Bits
The item indicates the end of a serial data packet. The standard setting is [1] Stop Bit.

3.3.4 CSM Configuration



Boot option filter

This option controls Legacy/UEFI ROMs priority.

Launch Storage OpROM Policy

Select UEFI only to run those that support UEFI option ROM only. Select Legacy only to run those that support legacy option ROM only. Select Do not launch to not execute both legacy and UEFI option ROM.

3.3.5 USB Configuration



Intel USB3.0 Mode

Use this item to select the mode of operation of Intel USB 3.0 controller. Configuration options: [Enabled], [Disabled], [Auto] and [Smart Auto]. If [Auto] is selected, all USB ports work as USB3.0 after boot to OS. If [Smart Auto] is selected, all USB ports work as USB3.0 after boot to OS and work as USB2.0 in deep sleep stages.

Legacy USB Support

Use this option to enable or disable legacy support for USB devices. The default value is [Enabled].

3.3.6 System Configuration


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
Advanced
Primary Graphics Adapter [PCI Express]
Onboard VGA [Auto]
Onboard LAN1 & LAN2 [Enabled]
Above 4G Decoding [Auto]
Restore on AC/Power Loss [Last State]
Select the type of primary VGA in case of multiple video controllers.
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

Primary Graphics Adapter

Use this item to select the type and primary VGA in case of multiple video contorllers.

Onboard VGA

Use this to enable or disable the Onboard VGA function. The default value is [Auto].

Onboard LAN1 & LAN2

This allows you to enable or disable both the Onboard LAN 1 & LAN 2 features.

Above 4G Decoding

Enable or disable 64bit capable Devices to be decoded in Above 4G Address Space (only if the system supports 64 bit PCI decoding).

Restore on AC/Power Loss

This allows you to set the power state after an unexpected AC/power loss. If [Power Off] is selected, the AC/power remains off when the power recovers. If [Power On] is selected, the AC/power resumes and the system starts to boot up when the power recovers. If [Last State] is selected, it will recover to the state before AC/power loss.

3.3.7 Hard Disk S.M.A.R.T Settings

Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
Advanced
Hard Disk S.M.A.R.T Settings
Hard Disk S.M.A.R.T [Disabled]
S.M.A.R.T stands for Self-Monitoring, Analysis, and Reporting Technology. It is a monitoring system for computer hard disk drives to detect and report on various indicators of reliability.
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

Hard Disk S.M.A.R.T.

Use this item to enable or disable the S.M.A.R.T. (Self-Monitoring, Analysis, and Reporting Technology) feature. Configuration options: [Disabled] and [Enabled].

3.3.8 3rd Storage Configuration



LSI 3008 Controller

Use this item to enable or disable LSI 3008 Controller. Press <Ctrl - C> to enter RAID ROM during UEFI POST process.

Bootable LSI 3008 Controller

Use this item to enable or disable Bootable LSI Controller.

3.3.9 H/W Monitor

In this section, it allows you to monitor the status of the hardware on your system, including the parameters of the CPU temperature, motherboard temperature, CPU fan speed, chassis fan speed, and the critical voltage.


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
Advanced
+3.3V : +3.264 V
+5V : +5.112 V
+12V : +12.091 V
ATX+5VSB : +5.010 V
+3VSB : +3.440 V
CPU1_VIN : +1.810 V
CPU2_VIN : +0.000 V
VCCM_AB : +1.210 V
VCCM_CD : +1.220 V
+1.05_PCH : +1.080 V
+1.50_PCH : +1.520 V
VCCM_EF : +0.000 V
VCCM_GH : +0.000 V
BAT : +3.120 V
CPU1_FAN : N/A
CPU2_FAN : N/A
REAR_FAN1 : N/A
FRNT_FAN1 : N/A
FRNT_FAN2 : N/A
FRNT_FAN3 : 3400 RPM
FRNT_FAN4 : N/A
MB Temp : 50.0 degrees C
Card side Temp : 42.0 degrees C
CPU1 Temp : 64.0 degrees C
CPU2 Temp : 0.0 degrees C
Fan Speed Control.
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

CPU1_FAN

This allows you to set the CPU 1 fan's speed. The default value is [Smart Fan].

CPU2_FAN

This allows you to set the CPU 2 fan's speed. The default value is [Smart Fan].

REAR_FAN 1

This allows you to set the rear fan 1's speed. The default value is [Smart Fan].

FRNT_FAN 1

This allows you to set the front fan 1's speed. The default value is [Smart Fan].

FRNT_FAN 2

This allows you to set the front fan 2's speed. The default value is [Smart Fan].

FRNT_FAN 3

This allows you to set the front fan 3's speed. The default value is [Smart Fan].

FRNT_FAN 4

This allows you to set the front fan 4's speed. The default value is [Smart Fan].

Smart Fan Control

This allows you to set the Smart fan's level speed.

Smart Fan Duty Control
Smart Fan Duty x (x means 1 to 11 stage)
This allows you to set duty cycle for each stage.

Smart Fan Temp Control
Smart Fan Temp x (x means 1 to 11 stage)
This allows you to set temperature for each stage.

Watch Dog Timer

This allows you to enable or disable, or configure watch dog timer feature. The default value is [Disabled].
Reset: System will reboot after being idle for 5 minutes.
NMI: System will display blue screen after boot to OS and being idle for 5 minutes.
System will display error message on the screen after boot to DOS and being idle for 5 minutes.

3.3.10 Instant Flash

Instant Flash is a UEFI flash utility embedded in Flash ROM. This convenient UEFI update tool allows you to update system UEFI without entering operating systems first like MS-DOS or Windows®. Just save the new UEFI file to your USB flash drive, floppy disk or hard drive and launch this tool, then you can update your UEFI only in a few clicks without preparing an additional floppy diskette or other complicated flash utility. Please be noted that the USB flash drive or hard drive must use FAT32/16/12 file system. If you execute Instant Flash utility, the utility will show the UEFI files and their respective information. Select the proper UEFI file to update your UEFI, and reboot your system after the UEFI update process is completed.

3.4 IntelRCSetup

In this section, you may set the configurations for the following items: Processor Configuration, CPU Power Management Configuration, Memory Configuration, IIO Configuration, PCH Configuration and Server ME Configuration.


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
Main Advanced IntelRCSetup Server Mgmt Security Boot Event Logs Exit
RC Revision 1.0.4
Processor Configuration
CPU Power Management Configuration
Memory Configuration
IIO Configuration
PCH Configuration
Server ME Configuration
Setup Warning:
Setting items on this Screen to incorrect values may cause system to malfunction!
Displays and provides option to change the Processor Settings
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

English

3.4.1 Processor Configuration


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
IntelRCSetup
Processor Configuration
Processor Socket Socket 1 Socket 2
Processor ID 000306F2* | N/A
Processor Frequency 2.300GHz | N/A
Processor Max Ratio 23 | 00
Processor Min Ratio 12 | 00
Microcode Revision 00000023 | N/A
L1 Cache RAM 896KB | N/A
L2 Cache RAM 3584KB | N/A
L3 Cache RAM 35840KB | N/A
Processor 1 Version Intel(R) Xeon(R) CPU E5 -2695 v3 @ 2.30GHz
Processor 2 Version Not Present
Per-Socket Configuration
Intel Hyper Threading Technology [Enable]
No-Execute Memory Protection [Enable]
Enable Intel TXT Support [Disabled]
Intel Virtualization Technology [Enable]
Enable SMX [Disabled]
Hardware Prefetcher [Enable]
Adjacent Cache Prefetch [Enable]
Change Per-Socket Settings
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

Per-Socket Configuration

Change Per-Socket Settings.

CPU Socket 1 Configuration

Active Processor Cores

Enter the number of cores to be enabled. 0 means all cores.

CPU Socket 2 Configuration

Active Processor Cores

Enter the number of cores to be enabled. 0 means all cores.

Intel Hyper Threading Technology

Intel Hyper Threading Technology allows multiple threads to run on each core, so that the overall performance on threaded software is improved.

No-Execute Memory Protection

Processors with No-Execution Memory Protection Technology may prevent certain classes of malicious buffer overflow attacks.

Enable Intel TXT Support

Enable Intel Trusted Execution Technology configuration. Please disable "EX DFX

Features" when TXT is enabled.

Intel Virtualization Technology

Intel Virtualization Technology allows a platform to run multiple operating systems and applications in independent partitions, so that one computer system can function as multiple virtual systems.

Enable SMX

Use this item to enable Safer Mode Extensions.

Hardware Prefetcher

Automatically prefetch data and code for the processor. Enable for better performance.

Adjacent Cache Prefetch

Automatically prefetch the subsequent cache line while retrieving the currently requested cache line. Enable for better performance.

3.4.2 CPU Power Management Configuration


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
IntelRCSetup
CPU Power Management Configuration
Intel SpeedStep Technology [Enable]
Intel Turbo Boost Technology [Enable]
Package C State Support [C6(Retention) state]
CPU C3 State Support [Disabled]
CPU C6 State Support [Enable]
Intel SpeedStep technology allows processors to switch between multiple frequencies and voltage points for better power saving and heat dissipation.
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

Intel SpeedStep Technology

Intel SpeedStep technology is Intel's new power saving technology. Processors can switch between multiple frequencies and voltage points to enable power saving. The default value is [Enabled]. Configuration options: [Enabled] and [Disabled]. If you install Windows® Vista™ / 7 / 8 and want to enable this function, please set this item to [Enabled]. This item will be hidden if the current CPU does not support Intel(R) SpeedStep technology.

Please note that enabling this function may reduce CPU voltage and lead to system stability or compatibility issues with some power supplies. Please set this item to [Disabled] if above issues occur.

Intel Turbo Boost Technology

Use this item to enable or disable Intel Turbo Boost Technology. Turbo Boost allows processor cores to run faster than marked frequency in specific conditions. The default value is [Enabled].

Package C State Support

Enable CPU, PCIe, Memory, Graphics C State Support for power saving.

CPU C3 State Support

Enable C3 sleep state for lower power consumption.

CPU C6 State Support

Enable C6 deep sleep state for lower power consumption.

3.4.3 Memory Configuration



Enforce POR

Enable to enforce POR restrictions for DDR4 frequency and voltage programming.

DRAM Frequency

If [Auto] is selected, the motherboard will detect the memory module(s) inserted and assign the appropriate frequency automatically.

ECC Support

Use this item to enable or disable DDR ECC Support.

MRC Fast Boot

When enabled, protions of memory reference code will be skipped when possible to increase boot speed.

Memory Information

Displays memory topology with DIMM population information.

Memory Map

Set memory mapping settings.

Channel Interleaving

Select to configure Channel Interleaving settings.

Rank Interleaving

Select to configure Rank Interleaving settings.

RAS Mode

Enable or disable RAS modes. Enabling Sparing and Mirroring is not supported. If enabled, Sparing will be selected.

3.4.4 IIO Configuration


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
IntelRCSetup
IIO Configuration
PCIE2 Link Width [Auto]
PCIE2 Link Speed [Auto]
PCIE4 Link Width [Auto]
PCIE4 Link Speed [Auto]
PCIE6 Link Width [Auto]
PCIE6 Link Speed [Auto]
PCI Express Global Options
PCI-E ASPM Support (Global) [L1 Only]
Configuration PCIe port Link Width
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

PCIE 2 Link Width

Use this item to select PCIE port Bifurcation for selected slot(s).

PCIE 2 Link Speed

This allows you to select PCIE 2 Link Speed. The default value is [Auto].

PCIE 4 Link Width

Use this item to select PCIE port Bifurcation for selected slot(s).

PCIE 4 Link Speed

This allows you to select PCIE 4 Link Speed. The default value is [Auto].

PCIE 6 Link Width

Use this item to select PCIE port Bifurcation for selected slot(s).

PCIE 6 Link Speed

This allows you to select PCIE 6 Link Speed. The default value is [Auto].

PCI-E ASPM Support

This option enables or disables the ASPM support for all downstream devices.

3.4.5 PCH Configuration


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
IntelRCSetup
PCH Configuration
PCI-E ASPM Support (Global) [L1 Only]
PCH sSATA Configuration
PCH SATA Configuration
This option enables / disables the ASPM support for all downstream devices.
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

PCI-E ASPM Support

This option enables or disables the ASPM support for all downstream device.

PCH sSATA Configuration

sSATA devices and settings

sSATA Controller

Use this item to enable or disable SATA Controller.

sSATA Mode Selection

Identify the SATA port is connected to Solid State Drive or Hard Disk Drive. Press <Ctrl+I> to enter RAID ROM during UEFI POST process.

sSATA Aggressive Link Power Mgnt

Use this item to enable or disable SALP.

sSATA Port 0 / 1 / 2 / 3

Hot Plug

Designates this port as Hot Plugglable.

Spin Up Device

If enabled for any of ports, Staggered Spin Up will be performed and only the drives which have this option enabled will spin up at boot. Otherwise all drives spin up at boot.

sSATA Rx Setting

Adjust sSATA DTLE DATA Values (0-15).

sSATA Device Type

Identify the SATA port connected to Solid State Drive or Hard Disk Drive.

PCH SATA Configuration

SATA devices and settings

SATA Controller

Use this item to enable or disable SATA Controller.

SATA Mode Selection

Identify the SATA port is connected to Solid State Drive or Hard Disk Drive. Press <Ctrl+I> to enter RAID ROM during UEFI POST process.

Support Aggressive Link Power Mgnt

Use this item to enable or disable SALP.

SATA Port 0 / 1 / 2 / 3 / 4 / 5

Hot Plug

Designates this port as Hot Plugglable.

Spin Up Device

If enabled for any of ports, Staggered Spin Up will be performed and only the drives which have this option enabled will spin up at boot. Otherwise all drives spin up at boot.

SATA Rx Setting

Adjust SATA DTLE DATA Values (0-15).

SATA Device Type

Identify the SATA port connected to Solid State Drive or Hard Disk Drive.

3.4.6 Server ME Configuration



Spread Spectrum

Use this item to select spread specturm mode.

3.5 Server Mgmt


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
Main Advanced IntelRCSetup Server Mgmt Security Boot Event Logs Exit
BMC Self Test Status PASSED
Wait For BMC [Enabled]
System Event Log
BMC network configuration
BMC Mac Backup Tool
Wait For BMC response for specified time out. In PILOTII, BMC starts at the same time when BIOS starts during AC power ON. It takes around 30 seconds to initialize Host to BMC interfaces.
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

Wait For BMC

Wait For BMC response for specified time out. In PILOTII, BMC starts at the same time when BIOS starts during AC power ON. It takes around 30 seconds to initialize Host to BMC interfaces.

System Event Log

Press <Enter> to change the SEL event log configuration.

SEL Components

Change this to enable ro disable all features of System Event Logging during boot.

Erase SEL

Use this to choose options for earsing SEL.

When SEL is Full

Use this to choose options for reactions to a full SEL.

Log EFI Status Codes

Use this item to disable the logging of EFI Status Codes or log only error code or only progress or both.

BMC Network Configuration

Press <Enter> to configure BMC Network parameters.

Configuration Address Source

Select to configure BMC network parameters statically or dynamically(by BIOS or BMC). Configuration options: [Unspecified], [Static], and [Dynamic].

Unspecified: BMC network parameters are configured by BMC itself.
Static: Manually enter the IP Address, Subnet Mask and Gateway Address in the BIOS for BMC LAN channel configuration.
Dynamic: IP address, Subnet Mask and Gateway Address are automatically assigned by the network's DHCP server.

To configure BMC network parameters using the BIOS setup, select either [Static] or [Dynamic] option.
To configure BMC network parameters using the BMC web interface, select [Unspecified] option.

When [Dynamic] or [Static] is selected, do NOT modify the BMC network settings on the IPMI web page.

BMC Mac Backup Tool

Use this to restore BMC Mac from the backup.

3.6 Security

In this section, you may set or change the supervisor/user password for the system. For the user password, you may also clear it.


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
Main Advanced IntelRCSetup Server Mgmt Security Boot Event Logs Exit
Supervisor Password Not Installed
User Password Not Installed
Supervisor Password
User Password
Set or change the password for the administrator account. Only the administrator has authority to change the settings in the UEFI Setup Utility. Leave it blank and press enter to remove the password.
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

Supervisor Password

Set or change the password for the administrator account. Only the administrator has authority to change the settings in the UEFI Setup Utility. Leave it blank and press enter to remove the password.

User Password

Set or change the password for the user account. Users are unable to change the settings in the UEFI Setup Utility. Leave it blank and press enter to remove the password.

3.7 Boot Screen

In this section, it will display the available devices on your system for you to configure the boot settings and the boot priority.


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
Main Advanced IntelRCSetup Server Mgmt Security Boot Event Logs Exit
Boot Option Priorities
Boot Option #1 [UEFI: Built-in EFI ...]
Boot From Onboard LAN [Disabled]
Setup Prompt Timeout 1
Bootup Num-Lock [On]
Boot Beep [Disabled]
Full Screen Logo [Enabled]
AddOn ROM Display [Enabled]
Sets the system boot order
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

Boot Option #1

Use this item to set the system boot order.

Boot From Onboard LAN

Use this item to enable or disable the Boot From Onboard LAN feature.

Setup Prompt Timeout

This shows the number of seconds to wait for setup activation key. 65535(0XFFFF) means indefinite waiting.

Bootup Num-Lock

If this item is set to [On], it will automatically activate the Numeric Lock function after boot-up.

Boot Beep

Select whether the Boot Beep should be turned on or off when the system boots up. Please note that a buzzer is needed.

Full Screen Logo

Use this item to enable or disable OEM Logo. The default value is [Enabled].

AddOn ROM Display

Use this option to adjust AddOn ROM Display. If you enable the option “Full Screen Logo” but you want to see the AddOn ROM information when the system boots, please select [Enabled]. Configuration options: [Enabled] and [Disabled]. The default value is [Enabled].

3.8 Event Logs


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
Main Advanced IntelRCSetup Server Mgmt Security Boot Event Logs Exit
Change Smbios Event Log Settings
View Smbios Event Log
Press <Enter> to change the Smbios Event Log configuration.
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

Change Smbios Event Log Settings

This allows you to configure the Smbios Event Log Settings.

When entering the item, you will see the followings:

Smbios Event Log
Use this item to enable or disable all features of the SMBIOS Event Logging during system boot.

Erase Event Log
The options include [No], [Yes, Next reset] and [Yes, Every reset]. If Yes is selected, all logged events will be erased.

When Log is Full
Use this item to choose options for reactions to a full Smbios Event Log. The options include [Do Nothing] and [Erase Immediately].

MECI (Multiple Event Count Increment)
Use this item to enter the increment value for the multiple event counter. The valid range is from 1 to 255.

METW (Multiple Event Time Window)
Use this item to specify the number of minutes which must pass between duplicate log entries which utilize a multiple-event counter. The value ranges from 0 to 99 minutes.

View Smbios Event Log

Press <Enter> to view the Smbios Event Log records.

All values changed here do not take effect until computer is restarted.

3.9 Exit Screen


Aptio Setup Utility – Copyright (C) 2013 American Megatrends, Inc.
Main Advanced IntelRCSetup Server Mgmt Security Boot Event Logs Exit
Save Changes and Exit
Discard Changes and Exit
Discard Changes
Load UEFI Defaults
Exit system setup after saving the changes.
F10 key can be used for this operation.
↔: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Option
F1: General Help
F7: Discard Changes
F9: Load UEFI Defaults
F10: Save and Exit
ESC: Exit
Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

Save Changes and Exit

When you select this option, the following message "Save configuration changes and exit setup?" will pop-out. Press <F10> key or select [Yes] to save the changes and exit the UEFI SETUP UTILITY.

Discard Changes and Exit

When you select this option, the following message "Discard changes and exit setup?" will pop-out. Press <ESC> key or select [Yes] to exit the UEFI SETUP UTILITY without saving any changes.

Discard Changes

When you select this option, the following message "Discard changes?" will pop-out. Press <F7> key or select [Yes] to discard all changes.

Load UEFI Defaults

Load UEFI default values for all the setup questions. F9 key can be used for this operation.

Chapter 4 Software Support

4.1 Install Operating System

This motherboard supports various Microsoft® Windows® Server 2008 R2 SP1 / 2012 / 2012 R2 / Linux compliant. Because motherboard settings and hardware options vary, use the setup procedures in this chapter for general reference only. Refer to your OS documentation for more information.

4.2 Support CD Information

The Support CD that came with the motherboard contains necessary drivers and useful utilities that enhance the motherboard's features.

4.2.1 Running The Support CD

To begin using the support CD, insert the CD into your CD-ROM drive. The CD automatically displays the Main Menu if "AUTORUN" is enabled in your computer. If the Main Menu does not appear automatically, locate and double click on the file "ASRSetup.exe" from the root folder in the Support CD to display the menu.

4.2.2 Drivers Menu

The Drivers Menu shows the available device's drivers if the system detects installed devices. Please install the necessary drivers to activate the devices.

4.2.3 Utilities Menu

The Utilities Menu shows the application softwares that the motherboard supports. Click on a specific item then follow the installation wizard to install it.

4.2.4 Contact Information

If you need to contact ASRock Rack or want to know more about ASRock Rack, welcome to visit ASRock Rack's website at http://www.ASRockRack.com; or you may contact your dealer for further information.

Chapter 5 Troubleshooting

5.1 Troubleshooting Procedures

Follow the procedures below to troubleshoot your system.

Always unplug the power cord before adding, removing or changing any hardware components. Failure to do so may cause physical injuries to you and damages to motherboard components.

1. Disconnect the power cable and check whether the PWR LED is off.
2. Unplug all cables, connectors and remove all add-on cards from the motherboard. Make sure that the jumpers are set to default settings.
3. Confirm that there are no short circuits between the motherboard and the chassis.
4. Install a CPU and fan on the motherboard, then connect the chassis speaker and power LED.

If there is no power...

1. Confirm that there are no short circuits between the motherboard and the chassis.
2. Make sure that the jumpers are set to default settings.
3. Check the settings of the 115V/230V switch on the power supply.
4. Verify if the battery on the motherboard provides ~3VDC. Install a new battery if it does not.

If there is no video...

1. Try replugging the monitor cables and power cord.
2. Check for memory errors.

If there are memory errors...

1. Verify that the DIMM modules are properly seated in the slots.
2. Use recommended DDR4 2133 R-DIMMs.
3. If you have installed more than one DIMM modules, they should be identical with the same brand, speed, size and chip-type.
4. Try inserting different DIMM modules into different slots to identify faulty ones.
5. Check the settings of the 115V/230V switch on the power supply.

Unable to save system setup configurations...

1. Verify if the battery on the motherboard provides ~3VDC. Install a new battery if it does not.
2. Confirm whether your power supply provides adaquate and stable power.

Other problems...

1. Try searching keywords related to your problem on ASRock Rack's FAQ page: http://www.asrockrack.com/support

5.2 Technical Support Procedures

If you have tried the troubleshooting procedures mentioned above and the problems are still unsolved, please contact ASRock Rack's technical support with the following information:

1. Your contact information
2. Model name, BIOS version and problem type.
3. System configuration.
4. Problem description.

You may contact ASRock Rack's technical support at:
http://www.asrockrack.com/support/tsd.asp

5.3 Returning Merchandise for Service

For warranty service, the receipt or a copy of your invoice marked with the date of purchase is required. By calling your vendor or going to our RMA website (http://event.asrockrack.com/tsd.asp) you may obtain a Returned Merchandise Authorization (RMA) number.
The RMA number should be displayed on the outside of the shipping carton which is mailed prepaid or hand-carried when you return the motherboard to the manufacturer. Shipping and handling charges will be applied for all orders that must be mailed when service is complete.

This warranty does not cover damages incurred in shipping or from failure due to alteration, misuse, abuse or improper maintenance of products.

Contact your distributor first for any product related problems during the warranty period.

Chapter 6: Net Framework Installation Guide

To let Intel® RSTe works properly, it is required to install Net Framework. Please follow the steps below to enable ".Net Framework" feature on Microsoft® Windows® Server 2008 R2.

6.1 Installing .Net Framework 3.5.1 (For Server 2008 R2)

1. Double-click the Server Manager icon in the Windows system tray.



2. Click Add Features in the right hand pane.


Server Manager (WIN-SR7J1MFF159)
Get an overview of the status of this server, perform top management tasks, and add or remove server roles and features.
Roles: 0 of 17 installed
Go to Roles
Add Roles
Remove Roles
Features Summary
Features Summary Help
Features: 1 of 42 installed
Add Features
Remove Features
Windows Process Activation Service
Process Model
.NET Environment
Configuration APIs
Resources and Support
Resources and Support Help
Help make Windows Server better by participating in the Customer Experience Improvement Program (CEIP).
Participate in CEIP
Report issues to Microsoft and get solutions to common problems by turning on Windows Error Reporting.
Turn on Windows Error Reporting
Browse technical resources for Windows Server, including how-to help, guides, web casts, and tools.
Windows Server TechCenter
Get connected with other Microsoft customers through online community resources.
Windows Server Community Center
Send us your feedback and feature suggestions to help make Windows better.
Send Feedback to Microsoft
Search the Microsoft Update Catalog for product updates, add-ons and optional software.
Search the Microsoft Update Catalog

3. Check the box next to .Net Framework 3.5.1 and then click **Next.**


Add Features Wizard
Select Features
Features
Confirmation
Progress
Results
Select one or more features to install on this server.
Features:
.NET Framework 3.5.1 Features
.NET Framework 3.5.1
WCF Activation
Background Intelligent Transfer Service (BITS)
BitLocker Drive Encryption
BranchCache
Connection Manager Administration Kit
Desktop Experience
DirectAccess Management Console
Failover Clustering
Group Policy Management
Ink and Handwriting Services
Internet Printing Client
Internet Storage Name Server
LPR Port Monitor
Message Queuing
Multipath I/O
Network Load Balancing
Peer Name Resolution Protocol
Quality Windows Audio Video Experience
Description:
Microsoft .NET Framework 3.5.1 combines the power of the .NET Framework 2.0 APIs with new technologies for building applications that offer appealing user interfaces, protect your customers' personal identity information, enable seamless and secure communication, and provide the ability to model a range of business processes.
More about features
< Previous
Next >
Install
Cancel

4. Click **Next** to continue.


Add Features Wizard
Web Server (IIS)
Features
Web Server (IIS)
Role Services
Confirmation
Progress
Results
Introduction to Web Server (IIS)
Web servers are computers that have specific software that allows them to accept requests from client computers and return responses to those requests. Web servers let you share information over the Internet, or through intranets and extranets. The Web Server role includes Internet Information Services (IIS) 7.0, a unified Web platform that integrates IIS 7.0, ASP.NET, and Windows Communication Foundation. IIS 7.0 also features enhanced security, simplified diagnostics, and delegated administration.
Things to Note
Using Windows System Resource Manager (WSRM) can help ensure equitable servicing of Web server traffic, especially when there are multiple roles on this computer.
The default installation for the Web Server (IIS) role includes the installation of role services that enable you to serve static content, make minor customizations (such as default documents and HTTP errors), monitor and log server activity, and configure static content compression.
Additional Information
Overview of Web Server (IIS)
Overview of Available Role Services in IIS 7.0
IIS Checklists
Common Administrative Tasks in IIS
Overview of WSRM
< Previous
Next >
Install
Cancel

5. Click **Install** to start installing .Net Framework 3.5.1.



6. After the installation completes, click **Close.**


Add Features Wizard
Installation Results
Features
Confirmation
Progress
Results
The following roles, role services, or features were installed successfully:
1 warning message below
Windows automatic updating is not enabled. To ensure that your newly-installed role or feature is automatically updated, turn on Windows Update in Control Panel.
.NET Framework 3.5.1 Features
Installation succeeded
The following features were installed:
.NET Framework 3.5.1
Print, e-mail, or save the installation report
< Previous
Next >
Close
Cancel